



# DOMINO SP SEAL → LOCKING PROCEDURE



**Diagram A**



**Diagram B**



**Diagram C**

## **STEP 1**

Make sure the seal head being placed with the front side facing the user, as shown in Diagram A.

## **STEP 2**

Hold the seal head using one hand and with the other, insert the metal strip at the entry hole, as shown in Diagram B.

## **STEP 3**

After inserting, push the metal strip in till the maximum and then pull it backwards for sealing, as shown in Diagram C. The two inspection holes at the strip should be aligned with each other after locking.